

Windows VB example for switching on and off the KMTronic USB One Relay



© KMTronic 2011

Downloads:

- FTDI drivers
<http://www.ftdichip.com/Drivers/VCP.htm>

Step by step instructions:

1. Download the drivers
2. Connect USB relay and install drivers
3. Check in Device Manager COM port where the Relay is installed (in this example it is COM Port 5)



Sample C# code:

```
private void button1_ON_Click(object sender, EventArgs e)
{
    serialPort1.Write(new byte[] { 0xFF, 0x01, 0x01 }, 0, 3);
}

private void button1_OFF_Click(object sender, EventArgs e)
{
    serialPort1.Write(new byte[] { 0xFF, 0x01, 0x00 }, 0, 3);
}
```

